



**Note:** In situations where the WANZ window bar is installed at Sill locations, the rear portion of the Superpol™ Sill Flashing can be removed and installed on top of the cavity batten allowing the window bar to be fixed suitably, See Detail SP 6

<b>Superpol™</b>	Title: <b>Standard Sill Detail</b>	
	Date. April 2014	Detail No. SP 5-0
This drawing must be read in conjunction with the Superpol Cladding Design Guide		