

Block overlap to be minimum 100mm



Depth of chasing not to be greater than 1/3 of wall thickness (generally snug fit)

Horizontal joints to be completely filled

Control joint ties to be placed at every second course crimp always facing up

Block damage to be repaired with Supercoat™ Superbond adhesive & Supercrete™ Block dust

All fixings to be an approved type. Refer Supercrete Fixings Guide

Joint thickness to be 2-3mm using Supercoat™ Superbond thin bed Adhesive

Excess adhesive to be removed

Control joints allowed for @ 6000mm maximum centres

Vertical joints to be completely filled with adhesive

Supercoat Superbase leveling mortar bed

Foundation to NZS 4229

DPC slip joint membrane to all walls on a support

Copyright © Superbuild International Ltd 2013

Supercrete™

Title:

Wall Construction Checklist

BLOCK CONSTRUCTION

Date: **September 2013**

Scale: **1:10**

Detail No. **BLK- 1.2**

This drawing must be read in conjunction with the Supercrete Block Design Guide