



LEGEND:

- AB = ANGEL BRACKET TO PROJECT SPECIFICATIONS
- SBR = BACKING ROD & SEALANT TO PROJECT SPECIFICATIONS
- CS = CONCRETE SUPPORT SLAB/BEAM/WALL
- EAB = EQUAL ANGLE BRACKET (ex MULTIBRACE)
- SSA = SUPERCOTE™ SUPERBOND ADHESIVE
- HWP = SUPERCOTE™ HORIZONTAL WALL PANELS
- LP = SUPERCOTE™ HORIZONTAL LINTEL PANEL
- NPF = NOTCH PANEL & FILL AS PER SPECIFICATIONS
- SAB = SLOTTED ANGLE BRACKET, REF TO DETAILS
- SP = SUPERCOTE™ HORIZONTAL SILL PANEL
- SSD = STAINLESS STEEL DOWELS, REF TO DETAILS
- TBM = DPC OR EQUIVALENT BOND BREAKER & THICK BEAD MORTAR
- VWP = SUPERCOTE™ VERTICAL WALL PANEL

Supercrete™

Title: CIWS Vertical Single Panel Width Opening Detail

CIWS CONSTRUCTION

Date: June 2013

Scale: N.T.S.

Detail No. 20.3.1

This drawing must be read in conjunction with the Supercrete Commercial & Industrial Wall Systems Design Guide